

ID Number	Name of Sound	ID Number	Name of Sound
072-000-000	Worlds Apart	072-000-064	A Classic
072-000-001	Good Vibes	072-000-065	Melody Maker
072-000-002	Thuer Bass	072-000-066	Bell Tinkle Pad
072-000-003	Oceanarium	072-000-067	Trance Orchestra
072-000-004	Heart Solo	072-000-068	Ethnic Pluck Loop
072-000-005	Club Rotation	072-000-069	Elektro Res Congas
072-000-006	Auto Synth	072-000-070	Big Pwm Strings
072-000-007	Unison Bend Poly	072-000-071	Jupiter Arp
072-000-008	Ice Cold Swe	072-000-072	Jupiter Thu
072-000-009	Atonal Percussachap	072-000-073	Square & Hold Pad
072-000-010	The Swarm	072-000-074	Joan's Lead
072-000-011	Soft Ambi Swes	072-000-075	Mind Machine
072-000-012	Ultraog Bass	072-000-076	Cou Pad
072-000-013	Big Dark Mega Pad	072-000-077	Soft Sweer Rlay
072-000-014	Ear Killer	072-000-078	Wave Pattern Pad
072-000-015	Aggressor Bass	072-000-079	M Drums 1
072-000-016	Outback	072-000-080	Falling Star Pad
072-000-017	Worlds Biggest Swe	072-000-081	Classic Dance Saws
072-000-018	Polyrhythm Pad	072-000-082	Fuzzy Chap
072-000-019	Real Analog Kit	072-000-083	De Sea
072-000-020	Tinkling Wavetable Pad	072-000-084	Vocality
072-000-021	Metalliga	072-000-085	Dance Solo
072-000-022	Hairy Bass	072-000-086	Arctic Circle
072-000-023	Big Ass Pad	072-000-087	Velo Perc Chordulator
072-000-024	Ghost Rave	072-000-088	Aurora
072-000-025	Rave Signal Squares	072-000-089	Elektro Noise Crash
072-000-026	Sundown	072-000-090	Mega Swe Pad
072-000-027	Ambient Chord	072-000-091	HS Bassline
072-000-028	Chaser Pad	072-000-092	LoFi Sinus
072-000-029	Fat Analog Bass Slap	072-000-093	Analog Pad
072-000-030	The Greek Pad	072-000-094	Classic Square Lead
072-000-031	Beaver Att. Formation	072-000-095	Fuzz Melody
072-000-032	CineIntroBass	072-000-096	Fishsex
072-000-033	Softly Softly Pad	072-000-097	Power Squared
072-000-034	TV Mystery	072-000-098	HP Dirty Swe Arp
072-000-035	Tech Siren	072-000-099	Soft Bell Mallets
072-000-036	Welcome	072-000-100	HP Dirty Swe
072-000-037	Wavypan	072-000-101	Phaser Sequence
072-000-038	S+H Worlds	072-000-102	Chorused E-Bass
072-000-039	Bubble Wave Electro	072-000-103	Days Gone By
072-000-040	Release Shatter Pad	072-000-104	Binder Lead
072-000-041	Creamy Arpeggio	072-000-105	Quaeko
072-000-042	Rubber Reso Bass	072-000-106	Paranoia Paranoia
072-000-043	Space Rescue Mission	072-000-107	Bright Brass Section
072-000-044	Sandy Solo	072-000-108	BP Dreams
072-000-045	Monster Rave Bass	072-000-109	Ano Rhodes
072-000-046	Salthar	072-000-110	Rich Sync Pad
072-000-047	Numan Strings	072-000-111	Triangle Arpeggio
072-000-048	Milkyway Pad	072-000-112	Buer Bass
072-000-049	Dark Bell	072-000-113	Mery Pad
072-000-050	Astral Strings	072-000-114	Aah Soloist
072-000-051	Fuzzy Gurgler	072-000-115	Techno Attack
072-000-052	Buzz Bass	072-000-116	Grain Brain
072-000-053	Digi Echo Pad	072-000-117	Wavebend Poly
072-000-054	Ultraog Lead	072-000-118	Caldera
072-000-055	Synchronas	072-000-119	J Drums 1
072-000-056	Lunar Eclipse	072-000-120	Touchy Swe Pad
072-000-057	Roundabout	072-000-121	Filter Super Drivio
072-000-058	Bubble Swe	072-000-122	FuzzaFizzle Bass
072-000-059	Drums of Death	072-000-123	Soft Rotor Sparkle Pad
072-000-060	Sad tion Pad	072-000-124	Square Bend Lead
072-000-061	Euro Chase Bass	072-000-125	Karma Lead
072-000-062	Thick Pulse Bass	072-000-126	S&H Noise
072-000-063	Rich Wave Bells Pad	072-000-127	Fat Sync Poly

ID Number	Name of Sound	ID Number	Name of Sound
073-000-000	Hyper Sweep Pad	073-000-064	Warm Horn
073-000-001	Percy RezNoiseInator	073-000-065	Trance Worlds
073-000-002	Digi Bell	073-000-066	Electrhodes
073-000-003	Hi Tone Bell	073-000-067	Sweeping Worlds
073-000-004	Reso Smack Bass	073-000-068	Punchy Sequence
073-000-005	Jet Pad	073-000-069	Thuy Stud Bass
073-000-006	Quad Saw Solo	073-000-070	Nightmare Lead
073-000-007	Phaser HP Sequencer	073-000-071	Dirty Dance Organ
073-000-008	Swirling Sync Keys	073-000-072	Vowelscapes
073-000-009	Horny	073-000-073	J Drums 2
073-000-010	Stutter Pad	073-000-074	Intro HighPass Pad
073-000-011	Analog Metal Perc	073-000-075	Noise Zap Arp
073-000-012	Century Pad	073-000-076	Filling Rattler
073-000-013	Stereo Sync Arp	073-000-077	Itchy Saws
073-000-014	Hollow Bass	073-000-078	Clavigue
073-000-015	Saw Pad Sweep	073-000-079	Traveller
073-000-016	Phat Solo Sync	073-000-080	Square Bells
073-000-017	Firus	073-000-081	Autotif Bass
073-000-018	Space Phase	073-000-082	Classic og Bass
073-000-019	SuperFizzy StringSynth	073-000-083	Brassy Saw Lead
073-000-020	Glocken Loop	073-000-084	OBlike
073-000-021	Chorus Bells	073-000-085	LFO ve
073-000-022	Mars n Venus	073-000-086	Big Wave Bells
073-000-023	Sile Saw Arpeggio	073-000-087	Journey To Pluto
073-000-024	Sub Bass Fattener	073-000-088	LFO Bass
073-000-025	Calorizer Pad	073-000-089	Self Oscillator
073-000-026	Develish Syncer	073-000-090	Smacky PWM
073-000-027	Ringtone Lead	073-000-091	Prophet Arp
073-000-028	Doom+Chaos	073-000-092	Bright Chimes
073-000-029	Hyper vs P	073-000-093	Kraftworks
073-000-030	Curves	073-000-094	DnB Sub Bass
073-000-031	Velo Perculator	073-000-095	Couter Games
073-000-032	Vocalizing	073-000-096	Rich Square Bell
073-000-033	Wicked Square Arp	073-000-097	Old School Tune
073-000-034	DnB Square	073-000-098	Phat Pwm Bass
073-000-035	Big Octave Pad	073-000-099	Square Sync Solo
073-000-036	Disto Sweep Lead	073-000-100	Soft Synth Brass
073-000-037	Big Drive Lead	073-000-101	Repeat Bass
073-000-038	Late Synbrass	073-000-102	OrgaThu Bass
073-000-039	Square Dance	073-000-103	Sweepy Pulse Lead
073-000-040	Warm EE Piano	073-000-104	Pure Wet Fat
073-000-041	Wavetable SweeperPad	073-000-105	Velocity BandBass
073-000-042	Transistor Bass Line	073-000-106	Drug Solo
073-000-043	Low Hangin Mumma	073-000-107	BP Brass
073-000-044	VS Choir Pad	073-000-108	Unitea Bass
073-000-045	Miss HipHop	073-000-109	Time For Flange
073-000-046	Filter Keys	073-000-110	Bass Of Death
073-000-047	Humble Stance	073-000-111	Detuned Stage Saws
073-000-048	Wave Line	073-000-112	M-Bassy
073-000-049	M Drums 2	073-000-113	P Vox Bell
073-000-050	Sync Sweep	073-000-114	Transistor Bass
073-000-051	Sweet Square Bell	073-000-115	SawPluck
073-000-052	Overtone Solo Bass	073-000-116	TriStar Bass
073-000-053	Soft Super Saw	073-000-117	Jupiter Keys
073-000-054	Interval og	073-000-118	UK Breakz Bass
073-000-055	Industrialised	073-000-119	Muckiphonic PulsStrings
073-000-056	Big Reso Bell	073-000-120	Bow Bass
073-000-057	Reso Gater	073-000-121	Proph 2
073-000-058	VS Bells	073-000-122	Fuzzy Bass Riff
073-000-059	Ambient Mind	073-000-123	Silky Synth Orchestra
073-000-060	Pinhead Arp	073-000-124	Metal BandBass
073-000-061	Single Osc Bass	073-000-125	Juicy PWM Poly
073-000-062	Organic Lead	073-000-126	Bad Black Bass
073-000-063	Phased Leader	073-000-127	Init Patch

ID Number	Name of Sound	ID Number	Name of Sound
072-000-064	A Classic	073-000-028	Doom+Chaos
072-000-114	Aah Soloist	073-000-106	Drug Solo
072-000-015	Aggressor Bass	072-000-059	Drums of Death
072-000-027	Ambient Chord	072-000-014	Ear Killer
073-000-059	Ambient Mind	073-000-066	Electrhodes
073-000-011	Analog Metal Perc	072-000-089	Elektro Noise Crash
072-000-093	Analog Pad	072-000-069	Elektro Res Congas
072-000-109	Ano Rhodes	072-000-068	Ethnic Pluck Loop
072-000-086	Arctic Circle	072-000-061	Euro Chase Bass
072-000-050	Astral Strings	072-000-080	Falling Star Pad
072-000-009	Atonal Percussachap	072-000-029	Fat Analog Bass Slap
072-000-088	Aurora	072-000-127	Fat Sync Poly
072-000-006	Auto Synth	073-000-076	Filling Rattler
073-000-081	Autotif Bass	073-000-046	Filter Keys
073-000-126	Bad Black Bass	072-000-121	Filter Super Drivio
073-000-110	Bass Of Death	073-000-017	Firus
072-000-031	Beaver Att. Formation	072-000-096	Fishsex
072-000-066	Bell Tinkle Pad	072-000-095	Fuzz Melody
072-000-023	Big Ass Pad	072-000-122	FuzzaFizzle Bass
072-000-013	Big Dark Mega Pad	073-000-122	Fuzzy Bass Riff
073-000-037	Big Drive Lead	072-000-082	Fuzzy Chap
073-000-035	Big Octave Pad	072-000-051	Fuzzy Gurgler
072-000-070	Big Pwm Strings	072-000-024	Ghost Rave
073-000-056	Big Reso Bell	073-000-020	Glocken Loop
073-000-086	Big Wave Bells	072-000-001	Good Vibes
072-000-104	Binder Lead	072-000-116	Grain Brain
073-000-120	Bouw Bass	072-000-022	Hairy Bass
073-000-107	BP Brass	072-000-004	Heart Solo
072-000-108	BP Dreams	073-000-003	Hi Tone Bell
073-000-083	Brassy Saw Lead	073-000-014	Hollow Bass
072-000-107	Bright Brass Section	073-000-009	Horny
073-000-092	Bright Chimes	072-000-100	HP Dirty Swe
072-000-058	Bubble Swe	072-000-098	HP Dirty Swe Arp
072-000-039	Bubble Wave Electro	072-000-091	HS Bassline
072-000-112	Buer Bass	073-000-047	Humble Stance
072-000-052	Buzz Bass	073-000-000	Hyper Sweep Pad
072-000-118	Caldera	073-000-029	Hyper vs P
073-000-025	Calorizer Pad	072-000-008	Ice Cold Swe
073-000-012	Century Pad	073-000-055	Industrialised
072-000-028	Chaser Pad	073-000-127	Init Patch
073-000-021	Chorus Bells	073-000-054	Interval og
072-000-102	Chorused E-Bass	073-000-074	Intro HighPass Pad
072-000-032	CineIntroBass	073-000-077	Itchy Saws
072-000-081	Classic Dance Saws	072-000-119	J Drums 1
073-000-082	Classic og Bass	073-000-073	J Drums 2
072-000-094	Classic Square Lead	073-000-005	Jet Pad
073-000-078	Clavigue	072-000-074	Joan's Lead
072-000-005	Club Rotation	073-000-087	Journey To Pluto
072-000-076	Cou Pad	073-000-125	Juicy PWM Poly
073-000-095	Couter Games	072-000-071	Jupiter Arp
072-000-041	Creamy Arpeggio	073-000-117	Jupiter Keys
073-000-030	Curves	072-000-072	Jupiter Thu
072-000-085	Dance Solo	072-000-125	Karma Lead
072-000-049	Dark Bell	073-000-093	Kraftworks
072-000-103	Days Gone By	073-000-038	Late Synbrass
072-000-083	De Sea	073-000-088	LFO Bass
073-000-111	Detuned Stage Saws	073-000-085	LFO ve
073-000-026	Develish Syncer	072-000-092	LoFi Sinus
073-000-002	Digi Bell	073-000-043	Low Hangin Mumma
072-000-053	Digi Echo Pad	072-000-056	Lunar Eclipse
073-000-071	Dirty Dance Organ	072-000-079	M Drums 1
073-000-036	Disto Sweep Lead	073-000-049	M Drums 2
073-000-034	DnB Square	073-000-022	Mars n Venus
073-000-094	DnB Sub Bass	073-000-112	M-Bassy

ID Number	Name of Sound	ID Number	Name of Sound
072-000-090	Mega Swe Pad	073-000-053	Soft Super Saw
072-000-065	Melody Maker	072-000-077	Soft Sweer Rlay
072-000-113	Mery Pad	073-000-100	Soft Synth Brass
073-000-124	Metal BandBass	072-000-033	Softly Softly Pad
072-000-021	Metalliga	073-000-018	Space Phase
072-000-048	Milkyway Pad	072-000-043	Space Rescue Mission
072-000-075	Mind Machine	072-000-073	Square & Hold Pad
073-000-045	Miss HipHop	073-000-080	Square Bells
072-000-045	Monster Rave Bass	072-000-124	Square Bend Lead
073-000-119	Muckiphonic PulsStrings	073-000-039	Square Dance
073-000-070	Nightmare Lead	073-000-099	Square Sync Solo
073-000-075	Noise Zap Arp	073-000-013	Stereo Sync Arp
072-000-047	Numan Strings	073-000-010	Stutter Pad
073-000-084	OBlike	073-000-024	Sub Bass Fattener
072-000-003	Oceanarium	072-000-026	Sundown
073-000-097	Old School Tune	073-000-019	SuperFizzy StringSynth
073-000-062	Organic Lead	073-000-067	Sweeping Worlds
073-000-102	OrgaThu Bass	073-000-103	Sweepy Pulse Lead
072-000-016	Outback	073-000-051	Sweet Square Bell
073-000-052	Overtone Solo Bass	073-000-008	Swirling Sync Keys
073-000-113	P Vox Bell	073-000-050	Sync Sweep
072-000-106	Paranoia Paranoia	072-000-055	Synchronas
073-000-001	Percy RezNoiseInator	072-000-035	Tech Siren
073-000-063	Phased Leader	072-000-115	Techno Attack
073-000-007	Phaser HP Sequencer	072-000-030	The Greek Pad
072-000-101	Phaser Sequence	072-000-010	The Swarm
073-000-098	Phat Pwm Bass	072-000-062	Thick Pulse Bass
073-000-016	Phat Solo Sync	072-000-002	Thuer Bass
073-000-060	Pinhead Arp	073-000-069	Thuy Stud Bass
072-000-018	Polyrhythm Pad	073-000-109	Time For Flange
072-000-097	Power Squared	072-000-020	Tinkling Wavetable Pad
073-000-121	Proph 2	072-000-120	Touchy Swe Pad
073-000-091	Prophet Arp	072-000-067	Trance Orchestra
073-000-068	Punchy Sequence	073-000-065	Trance Worlds
073-000-104	Pure Wet Fat	073-000-114	Transistor Bass
073-000-006	Quad Saw Solo	073-000-042	Transistor Bass Line
072-000-105	Quaeko	073-000-079	Traveller
072-000-025	Rave Signal Squares	072-000-111	Triangle Arpeggio
072-000-019	Real Analog Kit	073-000-116	TriStar Bass
072-000-040	Release Shatter Pad	072-000-034	TV Mystery
073-000-101	Repeat Bass	073-000-118	UK Breakz Bass
073-000-057	Reso Gater	072-000-012	Ultraog Bass
073-000-004	Reso Smack Bass	072-000-054	Ultraog Lead
073-000-096	Rich Square Bell	072-000-007	Unison Bend Poly
072-000-110	Rich Sync Pad	073-000-108	Unitea Bass
072-000-063	Rich Wave Bells Pad	072-000-087	Velo Perc Chordulator
073-000-027	Ringtone Lead	073-000-031	Velo Perculator
072-000-057	Roundabout	073-000-105	Velocity BandBass
072-000-042	Rubber Reso Bass	072-000-084	Vocality
072-000-126	S&H Noise	073-000-032	Vocalizing
072-000-038	S+H Worlds	073-000-072	Vowelscapes
072-000-060	Sad tion Pad	073-000-058	VS Bells
072-000-046	Salthar	073-000-044	VS Choir Pad
072-000-044	Sandy Solo	073-000-040	Warm EE Piano
073-000-015	Saw Pad Sweep	073-000-064	Warm Horn
073-000-115	SawPluck	073-000-048	Wave Line
073-000-089	Self Oscillator	072-000-078	Wave Pattern Pad
073-000-023	Sile Saw Arpeggio	072-000-117	Wavebend Poly
073-000-123	Silky Synth Orchestra	073-000-041	Wavetable SweeperPad
073-000-061	Single Osc Bass	072-000-037	Wavypan
073-000-090	Smacky PWM	072-000-036	Welcome
072-000-011	Soft Ambi Swes	073-000-033	Wicked Square Arp
072-000-099	Soft Bell Mallets	072-000-000	Worlds Apart
072-000-123	Soft Rotor Sparkle Pad	072-000-017	Worlds Biggest Swe